Panel Wiring Diagram Model S1 IR1 PT





814 AIRWAY AVENUE SUTHERLIN, OREGON

TELEPHONE (541) 459-4449

FACSIMILE: (541) 459-2884

Simplex Operation

High Level Alarm: This float activates the alarm light and audible alarm when lifted. The audible alarm may be silenced by pressing the illuminated PUSH TO SILENCE button on the front of the control panel. The alarm light will remain on until the float is lowered.

<u>Timer On & Off:</u> This float turns off the programmable timer when lowered. When this float is lifted the timer will be restarted. Note: The timer will start with its off cycle.

Programmable Timer: The timer turns the pump on and off in a pre-set cycle. Note: The timer will start with its off cycle.

Key

= Factory Wire
= Field Wire
= Alternate Field Wire
A = Audio Alarm, 115 VAC

AL = Alarm Light
AS = Audio Silence Switch AS = Audio Silence Switch
CSB = Controls Circuit Breaker
CR1 = Override Relay
IR = Intrinsically Safe Relay
- Motor Contactor

M = Motor Contactor
PCB = Pump Circuit Breaker
SR = Silence Control Relay
TL = Terminal Link

*Options
CT = Cycle Counter
ETM = Elapsed Time Meter

Remote Alarm Connections

 \bigcirc

Orenco Model AHW or equiv

Note: 115VAC signal is present during alarm conditions.

HT = Heater PL = Power Light PRL = Pump Run Light



